

Company	Brand	Model	SK		KT		LG	
			OS Ver	SC500	OS Ver	SC500	OS Ver	SC500
				Test Date		Test Date		Test Date
iPhone	iPhone 4	MC630KH	7.0.6					
	iPhone 4S	MD239KH	8.1.2					
			8.3					
	iPhone 5	MD298KH	8.0.0		8.0.0			
			8.3					
	iPhone 5S	MF354KH/A	8.0.0		8.0.2			
			8.3					
	iPhone 5C	MF321KH/A	7.0.4					
			8.3					
	iPhone 6	MGA472KH/A	8.0.0		8.1.2			
			8.2		11.2.6	○	180322	
			8.3					
	iPhone 6+	MGAA2KH/A	8.0.0		8.1.1			8.1.1
			8.2		10.3.2	○	180322	
iPhone 6S	MGAA2KH/A	8.3						
				11.2.6	○	180322		
iPhone 6S+	MGAA2KH/A							
				11.5.6	○	180322		
iPhone 7		11.4	○	180620				
iPhone 7+		11.4	○	180620				
iPhone 8		11.4	○	180620				
iPhone 8+		11.4	○	180620				
Google	Galaxy Nexus	SHW-M420S						
	Nexus 5	NEXUS 5			6.0.1	○	180322	
	Nexus 5X		7.0.1	○	161103			
	pixel XL		8.1.0	○	180402			8.0.0 ○ 180320
	pixel		8.1.0	○	180402			
	pixel 2		8.1.0	X	180509			

KT 미디어소리 직접 올려줘야함

단말기 이어잭 부분이없어
테스트 불가

Galaxy S2	SHW-M250KL			4.0.4	○	161027	4.1.2	○	180327
				4.4.2	○	180322			
Galaxy S2 LTE	SHV-E110S	4.1.2	○	161011					
Galaxy S2 HD	SHV-E120L						4.1.2	X	161010
Galaxy S III LTE	SHV-E210SKL					161027			
		4.4.4	○	180402			4.4.4	○	180327
Galaxy S4	SHV-E300SKL	4.4.2	○	180402	4.3.0	○	161027		
		5.0.1	○	161011	5.0.1	○	180322	5.0.1	○
Galaxy S4 LTE-A	SHV-E330SK	5.0.1	○	180402	5.0.1	○	180322		
Galaxy S4 Active	SHV-E470S	5.0.1	○	180402					
Galaxy S4 Zoom	SM-C105L						4.2.2	○	161010
Galaxy S5	SM-G900SKL				5.0.0	○	161027		
		6.0.1	○	180402	6.0.1	○	161215	6.0.1	○
Galaxy S5 LTE-A	SM-G906SKL				5.0.1	○	161027		
		6.0.1	○	161103	6.0.1	○	180322	6.0.1	○
Galaxy S6	SM-G920SKL	6.0.1	○	161103	6.0.1	○	161027	6.0.1	○
		7.0.0	○	180326	7.0.0	○	180322		
Galaxy S6 Edge	SM-G925SKL	6.0.1	○	161103	6.0.1	○	161027		추후확인
		7.0.0	○	180326	7.0.0	○	180322		
Galaxy S6 Edge +	SM-G928SKL	6.0.1	○	161103	6.0.1	○	161027	6.0.1	○
		7.0.0	○	180326					
Galaxy S7	SM-G930SK	6.0.1	○	161103	6.0.1	○	161215		
		7.0.0	○	180326	7.0.0	○	180322	7.0.0	○
Galaxy S7 edge	SM-G935SK	6.0.1	○	161103	6.0.1	○	161027	6.0.1	○
		7.0.1	○	180326	7.0.0	○	171218	7.0.0	○
Galaxy S8	SM-G950SN	7.0.0	○	180326				7.0.0	○
		7.1.1	○	180320	8.0.0	○	180322		
Galaxy S8+	SM-G955S	7.0.0	○	180326				7.0.0	○
								8.0.0	○
Galaxy S9	SM-G960N	8.0.0	○	180509					
Galaxy S9+	SM-G965N	8.0.0	○	180509					
Galaxy Note	SHV-E160SKL	4.0.4	○	161011					
					4.1.2	○	161027	4.1.2	○
Galaxy Note II	SHV-E250SKL	4.4.2	○	180402	4.4.2	○	161027	4.4.2	○
					4.4.2	○	161027		
Galaxy Note III	SM-N900SKL								
		5.0.0	○	180326	5.0.0	○	180322	5.0.0	○

LG미디어 사운드 직접 올려줘야함

LG 수리중이라 추후 확인예정

결제기를 먼저 켜고 3~4초 후
휴대폰 이어잭에 연결 필요
결제기를 먼저 켜고 3~4초 후
휴대폰 이어잭에 연결 필요

Samsung

Galaxy Note IV	SM-N910SKL			4.4.4	○	161027		5.1.1	○	161031
		6.0.1	○	180326	6.0.1	○	180322	6.0.1	○	180327
Galaxy Note IV S-LTE	SM-N916SL	6.0.1	○	161103				6.0.1	○	161031
Galaxy Note 5	SM-N920SKL	6.0.1	○	161103	6.0.1	○	161027		추후확인	
		7.0.0	○	180326	7.0.0	○	180322			
Galaxy Note8	SM-N950K				7.0.0	○	171204			
Galaxy Note Edge	SM-N915SKL							5.0.1	○	161031
		6.0.1	○	180402	6.0.1	○	180322	6.0.1	○	171222
Galaxy Note FE	SM-N935S	8.0.0	○	180807						
Galaxy A3 2016	SM-A310NO							6.0.1	○	180327
Galaxy A5	SM-A500SKL							5.0.1	○	180327
		6.0.1	○	180402	6.0.1	○	180320			
Galaxy A5 2016	SM-A510L							6.0.1	○	161031
Galaxy A5 2017	SM-A520SL	6.0.1	○	170601				6.0.1	○	170224
		7.0.0	○	180326				7.0.0	○	180327
Galaxy A7	SM-A700SL	6.0.1	○	180402	6.0.1	○	180322	6.0.1	○	180327
Galaxy A7 2016	SM-A710S	7.0.0	○	180326						
Galaxy A8	SM-A800SK	5.1.1	○	161103						
		6.0.1	○	161101	6.0.1	○	161215			
		7.0.0	○	180402	7.0.0	○	180322			
Galaxy A8 2016	SM-A810S	6.0.1	○	161216						
		7.0.0	○	180402						
Galaxy A8 2018	SM-A530N							7.1.1	○	180803
Galaxy A8 Star	SM-G885S	8.0.0	○	180802						
Galaxy J3 2016	SM-J320NO	6.0.1	○	180402				6.0.1	○	180320
Galaxy J3 2017	SM-J330L							7.0.0	○	180803
Galaxy J5	SM-J500K	5.1.1	○	180326						
					6.0.1	○	2			
Galaxy J5 2016	SM-J510S	6.0.1	○	161101				6.0.1	○	180327
Galaxy J5 2017	SM-J530L							7.0.0	○	180803
Galaxy J7	SM-J700K				5.1.1	○	180322			
Galaxy R Style	SHV-E170SK	4.1.2	○	180402	4.1.2	○	161027			
Galaxy Grand	SHV-E270KL				4.1.2	○	161027	4.1.2	○	180327

LG 수리중이라 추후 확인예정

SK, LG 승인시 시간 편차 있음.

연결되는데 20~30초 정도가량
소요됩니다(화면이 꺼지기 바로전
에 연결됩니다)

*KT전용모델

Ig동글초기화 응답 오래걸림/
승인시편차있음

Galaxy Grand 2	SM-G710SKL	4.4.4	○	180402	4.4.4	○	180322	4.4.4	○	180327
Galaxy Mega	SHV-E310SKL	4.4.2	○	180402	4.4.2	○	161027	4.4.2	○	161007
Galaxy Win	SHV-E500L							4.2.2	○	180327
Galaxy Camera	EK-KC120L							4.1.1	○	161010
Galaxy Zoom 2	SM-C115L							4.4.2	○	161010
Galaxy Alpha	SM-G850SKL	5.0.2	○	180326	5.0.2	○	180322	5.0.2	○	180327
Galaxy 7 2016	SM-A710SL	6.0.1	○	170601				6.0.1	○	161031
Galaxy Wide	SM-G600S	6.0.1	○	180326						
Galaxy Wide 2	SM-J727S	7.0.0								
Galaxy ON7	SM-G610SL	6.0.1	○	170601				6.0.1	○	170224
		7.0.0	○	180326				7.0.0	○	180327
Optimus LTE TAG	LG-F120KL							4.0.4	○	161010
					4.1.2	○	161027			
Optimus LTE II	LG-F160SKL	4.1.2	○	180402	4.1.2	○	180322	4.1.2	○	180327
Optimus Vu	LG-F100SL	4.0.4	○	161011				4.0.4	○	180327
Optimus Vu II	LG-F200SKL	4.4.2	○	161011	4.4.2	○	161027	4.4.2	○	161010
Optimus Vu III	LG-F300SKL	4.4.2	○	180402	4.4.2	○	180322	4.4.2	○	180327
Optimus G	LG-F180S	4.4.2	○	180402						
Optimus G2	LG-F320SKL	4.4.2	○	180402	4.4.2	○	180322	4.4.0	○	180327
		5.0.1	○	161004						
Optimus G3	LG-F400SK	5.0.0	○	180326	6.0.0	○	180322			
		6.0.0	○	161004						
Optimus G3 Beat	LG-F470L							4.4.2	○	180327
Optimus G3 Screen	LG-F490L							4.4.4	○	180327
Optimus G3 cat.6	LG-F460SK				5.0.1	○	180322			
		6.0.1	○	180326	6.0.0	○	171219			
Optimus G4	LG-F500SKL	6.0.1	○	161103	6.0.1	○	180322	6.0.1	○	180327
		7.0.0	○	180326	7.0.0	○	171219			
G5	LG-F700SKL	6.0.1	○	161103	6.0.1	○	161215	6.0.1	○	170904
		7.0.0	○	180326	7.0.0	○	180322	7.0.0	○	180327
G6	LGM-G600S	7.0.0	○	180402				7.0.0	○	180327
G7 Thin Q	LM-G710N							8.0.0	○	180801
V10	LG-F600SKL	5.1.1	○	161103	5.1.1	○	161215	5.1.1	○	161031
		6.0.1	○	161103	6.0.1	○	161027	6.0.1	○	170602
		7.0.0	○	180326	7.0.0	○	180322	7.0.0	○	170724
V20	LG-F800SK	7.0.0	○	180326	7.0.0	○	180322	7.0.0	○	180327
V30	LGM-V300S	8.0.0	○	180402				7.1.2	○	180320
V30+	LGM-V300SP	8.0.0	○	180402						
Optimus G Pro	LG-F240SKL	4.4.2	○	180326	4.4.2	○	161027			
								5.0.1	○	180327

SK여러번하면 한번되서 안된
다고 표기,LG기기고장으로 사용불
가

Optimus G Pro 2	LG-F350SKL	4.4.2			○	180322	4.4.2		○	180327
		5.0.1	○	180326			5.0.1		○	161010
Optimus G Flex	LG-F340KL	4.2.2			○	161027				
		4.4.2			○	180322	4.4.2		○	180327
Optimus G Flex 2	LG-F510SKL	5.1.1	○	161103			5.1.1	○		161031
		6.0.1	○	180326						
Optimus GX	LG-F310L						4.4.2		○	180327
Otimus Gx 2	LG-F430L						4.4.2		○	180327
F70	LG-F370L						4.4.2		○	180327
AKA	LG-F520KL	4.4.2			○	180322	4.4.2		○	180327
Volt	LG-F540L						5.0.2		○	180327
LG BandPlay	LG-F570S	6.0.1	○	161103						
LG Class	LG-F620L						5.1.1		○	180327
LG Stylus 2	LG-F720SL	6.0.1	○	180326			6.0.1		○	180327
X Screen	LG-F650SL	6.0.1	○	180326			6.0.1		○	180327
K10	LG-F670L						5.1.1		○	180327
LG U Phone	LG-F820L						6.0.1		○	180327
LG X 300	LGM-120L						7.0.0		○	180327
X Cam	LG-F690L						6.0.1		○	180327
LG X400	LGM-K121S	7.0.0	○	180326			7.0.0		○	180327
X POWER	LG-F750K				X	170621				
LG X500	LGM-X320L						7.0.0		○	180327
Q6	LGM-X600S	7.1.1	○	180320						
Q8	LGM-X800L						7.0.0		○	180803
X401	LG-X401	7.0.0	○	180402						
Nexus 5	LG-D821	6.0.1	○	180402						
Nexus 5X	LG-H791	8.1.0	○	180402						
프라다	LG-LU5400						4.0.4		○	180327
Optimus Big	LG-LU6800						4.0.4		○	180327
X4 PLUS	LG-X415S	7.0.2	○	180509			7.1.2		○	180803
Vega LTE	IM-A800S	4.0.4	○	161011						
Vega LTE M	IM-A810SK	4.0.4	X	161004	4.0.4	○	161027			
Vega LTE EX	IM-A820L						4.1.2		○	180327
Vega Racer	IM-A760									
Vega Racer II	IM-A830SKL						4.0.3		○	180327
		4.1.2	○	161011	4.1.2	○	161027			
Vega S5	IM-A840S	4.1.2	○	161011						
Vega R3	IM-A850SKL				4.1.2	○	161027	4.1.2	○	180327
		4.4.2	○	161004						

-> 볼륨 50% 해야 동작됨

KT전용모델

-> 볼륨 50% 해야 동작됨

-> 볼륨 50% 해야 동작됨

lg기기사용x

Pantech

	Vega No.6	IM-A860SKL	4.4.2	O	161011	4.4.2	O	180322	4.1.2	O	161010
	Vega Iron	IM-A870SKL	4.4.2	O	180402	4.4.2	O	180322	4.4.2	O	161010
	Vega LTE-A	IM-A880S	4.4.2	O	180402						
	Vega Seceret Note	IM-A890SKL	4.4.2	O	180326	4.4.2	O	180322	4.4.2	O	180327
	Vega Seceret Up	IM-A900SKL	4.4.2	O	180402	4.4.2	O	180322	4.4.2	O	180327
	Vega Iron 2	IM-A910SKL	4.4.2	O	180402	4.4.2	O	180322	4.4.2	O	180327
	IM100	IM-100K	6.0.1	O	180326	6.0.1	O	180322			
Huawei	X3	HW-H60-J1							4.4.2	X	180327
	화웨이 H	CAM-L32							6.0.1	O	180327
	화웨이 P9	EVA-L09							6.0.0	O	180327
	화웨이 P9+	VIE-L09							6.0.0	O	180320
	아너6	H60-L04				4.4.2	X	180322			
TG	LUNA	TG-L800S	6.0.1	O	161004						
	LUNA S	TG-900S	6.0.1	O	180326						
	OPPO R9	OPPO R9m	5.1	O	180326						
	Sol	AM-H200	5.0.2	O	180326						
	Sol Prime	T-1000	6.0.1	X	180509						
	Blackberry key one	BBB100-1							7.1.1	O	180320
	Blackberry PRIV	STV100-3	6.0.1	O	180326						
	Mi phone	MI NOTE LTE				6.0.1	O	180320			
	Redmi Note 4	Redmi Note 4	7.0.0	O	180509						
	MI MAX	MI MAX	6.0.1	X	180326						
	Mi A1	Mi A1	7.0.2	O	180509						
	Mi 5										
	Sony Xperia z3	D6653				6.0.1	O	180322			
	Sony Xperia z5										
	Sony Xperia xz	F8331	6.0.1	O	180509						
LG(Pad)	G Pad 8.0 LTE	LG-P490L							4.4.2	O	180327
	G Pad 8.3	LG-V500L							5.0.2	O	170224
	G Pad3 10.1	LG-P755L							6.0.1	X	180327

*SK외부대여로 추후확인예정

BLE(X) 동글을 두번에 나눠
꽂아야함(따닥)

*SK 전용폰

*SK 전용폰 , SK미디어 사운드
직접 올려줘야함

꽃은후에 전원을 켜야 연결됨(SK)

Apple (Pad)	iPad	MC496KH	6.13								
	New iPad	MD369KH	8.1.2								
			8.3								
	iPad 2	MC982KH	7.1.0								
			8.3								
	iPad mini	MD540KH	7.1.0								
			8.3								
	iPad retina	MD525KH/A			8.0.2						
	iPad mini retina	ME814KH/A	7.1.1								
	iPad Air	MD791KH/A	7.0.4								
			8.1.2								
			8.3		11.2.6	○	180322				
iPad MINI3	MGHW2KH/A	8.1.1									
		8.2		10.3.2	○	180322					
		8.3									
iPad Air2	MGL12WLL	8.1.1									
		8.2									
Samsung (Tab)	Galaxy Tab 7	SHW-M180S	2.3.6	○	161011						
	Galaxy Tab 8.9	SHV-E140L					4.0.4	○	170224		
	Galaxy Tab 10.1	SHW-M380S	4.0.4	○	161014						
	Galaxy Note 10.1 3G	SHW-M480S	4.4.4	○	161011						
	Galaxy Note 10.1 LTE	SHV-E230KL				4.1.2	○	161027	4.4.4	○	170224
	Galaxy Note 10.1 201	SM-P605L									
	Galaxy Tab 4	SM-T335L				4.4.2	○	180320	5.1.1	○	170224
						5.1.1	○	180322			
	Galaxy Tab S 8.4	SM-T705S	5.0.2	○	180402						
	Galaxy Tab S 10.5	SM-T805SKL	5.0.2	○	161011	4.4.4	○	180322			
			6.0.1	X	180402	6.0.1	X	171219	6.0.1	○	170224
	Galaxy Tab S3 9.7	SM-T825	7.0.0	○	180326						
	Galaxy W	SM-T255S	4.3	○	161011						
	Galaxy Tab A6	SM-T280	5.1.1	X	180326						
	Galaxy Tab E	SM-T375L						5.1.1	○	170224	
	Galaxy Tab E	SM-T378L						6.0.1	○	171222	
	Galaxy Tab A 2016	SM-T580	6.0.1	○	180326						
Galaxy Tab A 2017	SM-T385S	7.1.1	○	180326			7.1.1	○	180320		

LG 루팅되어있어서 확인불가